



Automobile Tire Pressure Gauge

مقياس ضغط إطارات السيارات

Product Introduction

The automobile tire pressure gauge is used to measure tire pressure. It helps prevent tire wear and reduces the risk of tire puncture.

[Pressure Range]: Calibrated to 50 LBS

Instructions

The steps for measuring tire pressure are as follows:

1. Remove the cap from the tire valve stem.
2. Open the box and take out the tire pressure gauge.
3. Connect the gauge to the tire valve, press down, and hold until the dial shows the pressure.
4. Remove the gauge from the valve – the measurement is now complete.

مقدمة المنتج

يُستخدم مقياس ضغط الإطارات لقياس ضغط إطارات السيارات. يساعد في تقليل تآكل الإطارات ويقلل من خطر انفجار الإطارات.
نطاق الضغط : معاير حتى 50 رطل

طريقة الاستخدام

خطوات قياس ضغط الإطارات كالتالي

1. قم بإزالة الغطاء من صمام الإطار
2. افتح العلبة وأخرج مقياس ضغط الإطارات
3. ضع طرف المقياس على صمام الإطار، واضغط عليه، واحتفظ به حتى يظهر المؤشر الضغط
4. أزل المقياس من الصمام، وهكذا تكون عملية القياس قد اكتملت

